# Raspberry Pi Zero W RGB Image Processor

This document is explaining how to make simple Image Processor with a Raspberry Pi Zero W. The image processing is just to determine if an object is red, green or blue. It is good starting point to learn how images can be processed with a Raspberry Pi.

# Raspberry Pi RGB Image Items

Following three items are the only parts necessary to make the RGB Image Processor:

#### 1. Raspberry Pi Zero W



## 2. Camera Raspberry Pi v2 8MP



#### 3. RGB Items



## Raspberry Pi Zero Setup

#### Operating Systems

The first thing to do to setup and install the OS on the Raspberry Pi Zero W.

The easiest way is to use the Raspberry Pi imager if there was not a pre-installed OS on a microSD when the Raspberry Pi Zero W was purchased. The instruction on how to install the OS and to download the imager can be found on following link:

https://www.raspberrypi.org/software/

Note that the maximum recommended microSD Card size for Raspberry Pi models is 32GB.

#### Remote Access

The second thing is to install the VNC on the your Raspberry Pi Zero W to get remote access. Open the Terminal on your Raspberry Pi and type following commands

sudo apt-get update sudo apt-get upgrade sudo apt-get install realvnc-vnc-viewer

The third thing is to install the VNC on the your Windows/MacOS/Linux to be able to control your Raspberry Pi unit remotely.

In the following link you will find the VNC download for you OS system:


https://www.realvnc.com/en/connect/download/vnc/macos/

Following video is also showing on hoe to make remote access:

https://www.youtube.com/watch?v=JZ1pdVVTMrw

#### Raspberry Pi configuration

To be able to work remotely and to use the camera it is important that the Camera and VNC Interfaces in the Raspberry Pi configuration setting are enabled as follows:



# Raspberry Pi Camera wiring and camera enabling

Following link explains how to connect the camera:

https://projects.raspberrypi.org/en/projects/getting-started-with-picamera/2

The physical connection should look like this:



In this configuration a transparent case was added for the camera but this is not necessary for the RGB Image processor to work.

# Raspberry Pi Camera Python Libraires

Before the python coding it is important that following python libraires are installed Use the terminal of the Raspberry IP. Before installing the libraries do an update by following command: sudo apt update

Numpy (For working with image arrays) sudo apt install python3-numpy

Matplotlib (For image plotting) sudo apt install python3-matplotlib


Opency (For image processing) sudo apt install python3-opency

Imagemagick (For displaying images) sudo apt install imagemagick

# The Raspberry Pi Zero testbed for Image Processing

## The RBG Test Objects

These are the RBG objects and the Raspberry Pi Zero W that was used in the test environment.



#### The testbed setup

The Raspberry Pi v2. Camera needs more or less 50cm to have a focus therefore in the figure below you can see the final testbed.



To get closer to a small object the "Camera.zoom" can then be used.


# Raspberry Pi Camera Python Codes

#### imageprocessing01.py

This python code is to test the camera.

It will take a picture and and save it as a png file and also show it on the screen.

```
from picamera import PiCamera
import numpy as np
from PIL import Image
Camera = PiCamera()
                                                                                                            # Initialize Camera
ImageSize = (1920, 1080)
                                                                                                            # Define Full HD
ImageSize [1/32), 1809)
CameraResolution = (int(16*np.floor(ImageSize[1]/32)),int(16*np.floor(ImageSize[0]/32)))
Camera.resolution = (CameraResolution[1],CameraResolution[0])
                                                                                                            # Adjust Resolution
                                                                                                            # Define Resolution
Camera.zoom = (0.3, 0.7, 0.3, 0.3)
                                                                                                            # Zoom in Object
input("Press enter to capture a Test Image <<cameratest.png>>")
Camera.start_preview()
                                                                                                            # Capture RGB Image
Camera.capture('cameratest.png')
TestImage = Image.open('cameratest.png') \\
                                                                                                            # Show Test Image
TestImage.show()
Camera.stop_preview()
```




#### imageprocessing02.py

This pythoncode code show a simplest method for plotting the images is using matplotlib's 'imshow' function, which plots all three RGB colors in a traditional format seen by the human eye.

```
from picamera import PiCamera
import numpy as np
import matplotlib.pyplot as plt
Camera = PiCamera()
                                                                                                 # Initialize Camera
ImageSize = (1920, 1080)
                                                                                                 # Define Full HD
CameraResolution = (int(16*np.floor(ImageSize[1]/32)),int(16*np.floor(ImageSize[0]/32)))
Camera.resolution = (CameraResolution[1],CameraResolution[0])
                                                                                                 # Adjust resolution
                                                                                                 # Define Resolution
RGBImage = np.empty((CameraResolution[0], CameraResolution[1],3), dtype=np.uint8)
                                                                                                 # Preallocate image
while True:
     input("Press enter to capture an RGB Image or press CTRL+C to exit")
     Camera.zoom = (0.3, 0.7, 0.3, 0.3)
                                                                                                 # Zoom in Object
     Camera.capture(RGBImage,'rgb')
                                                                                                 # Capture RGB image
     plt.imshow(RGBImage)
                                                                                                 # Display as Image
     RGBImage = np.empty((CameraResolution[0],CameraResolution[1],3),dtype=np.uint8)
                                                                                                 # Clear Memory
    plt.show()
                                                                                                 # Show RGB Image
  except KeyboardInterrupt:
                                                                                                 # Press CTRL+C to exit
    break
```


The plot should look something like the figure below, where the image's origin is the top left corner of the plot. We will be using this as the general layout for analyzing the images.



#### imageprocessing03.py

This code decompose the image into its three color components: red, green, and blue.

```
from picamera import PiCamera
import numpy as np
import matplotlib.pyplot as plt
Camera = PiCamera()
                                                                                                        # Initialize Camera
ImageSize = (1920, 1080)
CameraResolution = (int(16*np.floor(ImageSize[1]/32)),int(16*np.floor(ImageSize[0]/32)))
                                                                                                        # Full HD
                                                                                                        # Adjust resolution
Camera.resolution = (CameraResolution[1], CameraResolution[0])
                                                                                                        # Define Resolution
Camera.zoom = (0.3, 0.7, 0.3, 0.3)
                                                                                                        # Zoom in Object
RGBImage = np.empty((CameraResolution[0], CameraResolution[1], 3), dtype = np.uint8)
                                                                                                        # Preallocate Image
x,y = np.meshgrid(np.arange(np.shape(RGBImage)[1]), np.arange(0,np.shape(RGBImage)[0]))
                                                                                                        # Setup 2x2
while True:
     input("Press enter to capture a RGB Component Plot or press CTRL+C to exit"")
     Camera.capture(RGBImage,'rgb')
                                                                                                        # Capture RGB image
     fig,axn = plt.subplots(2,2,sharex=True,sharey=True)
                                                                                                        # Setup 2x2 plot grid
     fig.set_size_inches(9,7)
                                                                                                        # Set plot size
     Ing.set_SIZe_Inc.nes(x,r)
axn[0,0].pcolormesh(x,y,RGBImage[:;,,0],cmap='gray')
axn[0,1].pcolormesh(x,y,RGBImage[:;,,1],cmap='gray')
axn[1,0].pcolormesh(x,y,RGBImage[:;,,2],cmap='gray')
                                                                                                        # Get R Image Data
# Get G Image Data
                                                                                                        # Get B Image Data
     axn[1,1].imshow(RGBImage,label='Full Color')
                                                                                                        # Get RGB Image Data
     axn[0,0].title.set_text('Red')
                                                                                                        # Set plot 1 Title
     axn[0,1].title.set\_text('Green')
                                                                                                        # Set plot 2 Title
     axn[1,0].title.set_text('Blue')
                                                                                                        # Set plot 3 Title
     axn[1,1].title.set_text('All')
                                                                                                        # Set plot 4 Title
     print('Plotting images...')
     plt.imshow(RGBImage)
                                                                                                        # Display as Image
     RGBImage = np.empty((CameraResolution[0], CameraResolution[1], 3), dtype = np.uint8)
                                                                                                        # Clear Memory
     plt.savefig('Component_plot.png',dpi=150)
                                                                                                        # Save Component Plot
     plt.show()
                                                                                                        # Show Image
     plt.close()
                                                                                                         # Press CTRL+C to exit
   except KeyboardInterrupt:
```



Here you can see in the first three pictures the image decomposed into its three color components: red, green, and blue

#### imageprocessing04.py

This is the final code is a simple introduction to image processing. It will analyze the color content in an image. In this case it is used normally distributed mean and standard deviation.

```
import time
from picamera import PiCamera
import numpy as np
import matplotlib.pyplot as plt
import cv2 as cv
Camera = PiCamera()
                                                                                                                         # Initialize Camera
ImageSize = (1920, 1080)
                                                                                                                         # Full HD
CameraResolution = (int(16*np.floor(ImageSize[1]/32)),int(16*np.floor(ImageSize[0]/32)))
                                                                                                                         # Adjust resolution
Camera.resolution = (CameraResolution [1], CameraResolution [0]) \\
                                                                                                                         # Define Resolution
Camera.zoom = (0.35, 0.75, 0.2, 0.2)
                                                                                                                         # Object Zoom
RGBImageRaw = np.empty((CameraResolution[0], CameraResolution[1], 3), dtype = np.uint8)\\
                                                                                                                         # Preallocate Image
RGBImage = np.empty((CameraResolution[0], CameraResolution[1], 3), dtype = np.uint8)
                                                                                                                         # Preallocate Image
                                                                                              # Fix Framerate
Camera.framerate = 30
                                                                                              # Settle Camera
time.sleep(2)
Camera.iso = 200
                                                                                              # Fix ISO value
Camera.shutter_speed = Camera.exposure_speed
                                                                                              # Fix shutter speed
Camera.exposure\_mode = 'off'
                                                                                              # Fix White Balance
gain_set = Camera.awb_gains
                                                                                              # AWB Ouerv
Camera.awb mode = 'off
                                                                                              # Fix exposure gains
                                                                                              # Set AWB
Camera.awb_gains = gain_set
Noise = np.empty((CameraResolution[0], CameraResolution[1], 3), dtype=np.uint8)\\
                                                                                              # Preallocate Image
x,y = np.meshgrid(np.arange(np.shape(RGBImage)[1]), np.arange(0,np.shape(RGBImage)[0])) \\
                                                                                              # Create Rectangular grid
rgb_text = ['Red','Green','Blue']
                                                                                              # Array for naming color
input("Press enter to capture background noise image (Remove Background Noise)")Camera.capture(Noise, 'rgb')
                                                                                                                         # Capture Background Noise
RGBImage = cv.subtract(RGBImageRaw, Noise)
                                                                                                           # Substract Noise
while True:
     input("Press enter to capture an RGB Image or press CTRL+C to exit")
     Camera.capture(RGBImage,'rgb')
                                                                                                           # Capture RGB image
                                                                                                                         # Define Mean Vector
     mean = \prod
                                                                                                                         # Define STDev Vector
     for c in range(0,3):
                                                                                                           # Calculate Mean and STDev
      mean.append(np.mean(RGBImage[:,:,c]-np.mean(RGBImage)))\\
                                                                                                           # Append Mean value
     std.append(np.std(RGBImage[:,:,c]-np.mean(RGBImage)))\\ print(rgb\_text[c]+'---mean: \{0:2.2f\}, stdev: \{1:2.2f\}'.format(mean[c],std[c]))\\
                                                                                              # Append STDev valie
     print('The Object is: {}'.format(rgb_text[np.argmax(mean)]))
     plt.imshow(RGBImage)
                                                                                                           # Plot image
                                                                                              # Clear Memory
     RGBImage = np.empty((CameraResolution[0], CameraResolution[1], 3), dtype=np.uint8)
    plt.show()
                                                                                                                         # Show the image
  except KeyboardInterrupt:
                                                                                                           # Press CTRL+C to exit
    break
```

As you can see in code the we have fixed the shutter speed and the white balance, This is done for not letting the camera change these parameters after each taken image. We need also to subtract the background before we do any RGB test. This to avoid any background color to interfere.


## Raspberry Pi Camera RGB Image Processing Test

To see if the RGB Image Processing is working do following:

Run the the imageprocessing04.py without any object to until the program reach done the "Press enter to capture background noise image (Remove Background Noise" and reached the "Press enter to capture an RGB Image or press CTRL+C to exit". Before pressing enter, place an object with red, green or blue color. The result should match the color of the object.

#### **Red Objects**


Here is the result of a red object:



The Red has a highest mean (10,32) and therefore the object was interpreted as red.


#### **Green Objects**

Here is the result of a green object:



The Green has a highest mean (2,61) and therefore the object was interpreted as green.

# Blue Objects



The Blue has a highest mean (3,04) and therefore the object was interpreted as blue.


## Final Words and caution

If you have followed all the steps and setups the RGB Image Processing should work just fine. Try with different object to see if it is work.

One thing important is that with this simple configuration there must be white light. If you use yellow light you probable will get following result:


## The testbed setup with yellow light

In this testbed the light came from a yellow led.



## **Red Objects**


Here is the result of a red object:



The red has a highest mean (10,73) and therefore the object was interpreted correctly as red.

# **Green Objects**


Here is the result of a green object:



The Blue has a highest mean (1,88) and therefore the object was interpreted as blue. This is wrong and this is because of the yellow light. Therefore to make it work you need to use white light.

# Blue Objects

Here is the result of a blue object:



The blue has a highest mean (8,03) and therefore the object was interpreted as blue. Which is correct.